



FJERNVARME FYN AFFALDSENERGI ODENSE

**Safety and behaviour rules when driving on
the premises and during unloading**

BRÜNING
GROUP

Welcome to Fjernvarme Fyn

Address: Fjernvarme Fyn, Port/gate number 4, Havnegade 120 - 5000 Odense C

Opening hours: Monday till Friday from 9 am to 18 pm

Speed limit: max. 20 km/h factory premises

Emergency number: +45 2137 3863

Safety clothing



1. The truck must be weighed on the truck scales on entry (gross) - and again on exit (tare).
2. Safety: as soon as the driver is outside his truck, he must wear a vest with a signal colour. This way he is visible to the dumper driver.
3. The supplier-specific card for the truck scales is used for weighing. (If this card is not a permanent fixture in the truck, it is possible to borrow a card from the dumper driver, but please note that this card must always be returned). The card is saved on arrival and departure - please enter project number, cubic metres and kilometres. If the weighing is authorised, a bar code will be written out. If the screen is empty, please print lightly on the screen image. If you still do not receive a barcode, please contact the dumper driver.
4. After the instruction of a dumper driver the splitter will be unloaded on the splitter place.
5. Please collect a Dalum bag. You will find the bags behind the grey door at the corner of the power station. You may only use Dalum bags and these bags must not be part of the lorry.
6. During the unloading of the truck, the driver must remain in the truck cabin with the doors and windows closed to avoid inhaling wood dust and fungal spores, which can be harmful to health.
7. After unloading, a splinter sample is taken (a mixture of truck and trailer). Sampling instructions: Take a handful of splinters from 10 different places in the pile of splinters. Pour the splinters into the Dalum bag. When removing the splinters, your hand should be completely covered by splinters so that your hand cannot be seen. The sample is used to determine the water content.

8. You can close the bag with the automatic closing machine behind the grey door. Please place the receipt with the barcode from the weighing visible in the bag pocket.
9. The splinter sample must be placed in the orange bucket (signo. FLIS) to the left of the door.
10. The same card is used again at the exit. A weighing voucher is written out and is documentation of the unloading.
11. The plant can and will take parallel samples of the splinters before the truck has left the unloading point. The splinter samples are taken as random samples.

We will inform the suppliers of the result of the splinter sample.

BRÜNING
GROUP

Landstraße 30, 28870 Fischerhude, Germany

Tel. +49 4293 78 94 - 0
mail@bruening-group.de

www.bruening-group.com