



VEJEN VARMEVÆRK A.M.B.A.

**Safety and behaviour rules when driving on
the premises and during unloading**

BRÜNING
GROUP

Welcome to Vejen Varmeværk a.m.b.a.

Address: Navervej 5, 6600 Vejen

Emergency number: +49 151 118 198 23

Important document: Brüning Delivery Note

1. Safety clothing



2. Weighing in

Drive to the external weighbridge.



Hold the barcode from the Brüning delivery note under the scanner on the scales. Please take the weighing slip with you and continue to the bunker to unload.




4. Unloading & Sampling



Reverse up to the door until the truck is detected and the **laser lights** up red.



To open the Gate:
Enter the code **1234**



Do not unload above the maximum line!
When delivering in a walking floor truck, both bunkers must be filled!

Capacity per bunker:
75 - 80 lcm



Take a sample bucket from the cupboard and fill it with a sample from your lorry, place the weighing slip in the bucket as a sample.



Open the hatch with the code, place the sample bucket in the hatch and close it.



After unloading, drive forwards until you are outside the sensors. Go back to the switch and press the down arrow. The gate closes and stops 1/2 metre above the ground. The remaining wood chips can be swept into the pit, press the down arrow again and the gate closes completely.



4. Weigh out

Drive back to the scales and weigh yourself. Please take the printed weighing slip with you. **Good ride!**

General safety regulations:

If you damage the barrier or other equipment, you must report this immediately to the pitch staff. The repair costs will be charged to you. The unloading procedure must be followed. Violation of the safety regulations can be penalised with immediate expulsion from the site. AT leaflet D.2.2 from the Danish Working Environment Authority must be followed. This means that the employers (incineration plant and the drivers' employers) are obliged to co-operate in the implementation of the health and safety regulations on the plant premises. The obligation to co-operate means that the regulations that apply to the employees of the incineration plant must also be followed by the drivers. The instructions of the plant personnel must be followed.

Video surveillance

The plant is under video surveillance.

Alcohol and intoxicants

It is prohibited to enter the factory premises under the influence of alcohol or drugs or to consume alcohol or drugs.

Smoking policy

Smoking is not permitted.

BRÜNING
GROUP

Auf der Muggenburg 44, 28217 Bremen, Germany

Tel. +49 421 - 64361 0
mail@bruening-group.de

www.bruening-group.com